

Cab and Chassis Install Kit

(P/N CANDC)

Kit Includes:

 5/8"-11 Bolts x 8

 5/8"-11 Nuts x 8

 5/8" Lock Washers x 8

 5/8" Flat Washers x 16

3/8" x 2 1/2" x 8" Flats x 8

