

(P/N 38 DODGE)

Dodge 38" Frame Install Kit

Kit Includes:

 5/8"-11 x 2" Bolts x 6


 5/8"-11 x 4 1/2" Bolts x 6

 5/8"-11 Nuts x 12

 5/8" Lock Washers x 12

 5/8" Flat Washers x 24

3" x 4' x 14" Angle x 2



3" x 4' x 4" Angle x 4



3/8" x 2 1/2" x 8" Flats x 2

