

Dodge 42" Frame Install Kit (P/N 42 DODGE)

Kit Includes:

-  5/8"-11 x 2" Bolts x 4
-  5/8"-11 x 4 1/2" Bolts x 4
-  5/8"-11 Nuts x 8
-  5/8" Lock Washers x 8
-  5/8" Flat Washers x 16
- 3" x 4" x 4" Angle x 4
- 
- 3/8" x 2 1/2" x 8" Flats x 4
- 

