

(P/N FORD)
Older Ford Install Kit

Kit Includes:

 5/8"-11 Bolts x 8

 5/8"-11 Nuts x 8


 5/8" Lock Washers x 8

 5/8" Flat Washers x 16

3/8" x 2 1/2" x 8" Flats x 8



1 1/2" Tube x 16" x 2 (optional used for Shortbeds)



2" Tube x 16" x 2



2" Tube x 12" x 2

